

WiFi 6E Wireless Card Intel AX211 NGW M.2: CNVio2, Bluetooth 5.3, Tri-Band 5400Mbps, Network Adapter for Laptop Support Windows 10/11 (64bit), Linux, Chrome OS. Only Available with Gen 12+ CPU

Référence : AX211



AX211 Carte réseau sans fil

Plus rapide | Une transmission plus stable | BlueTooth 5.3

- Wifi 6E
- BT 5.3
- 2.4Gbps
- WPA3

Intel® Model: AX211NGW
Anatel: 12069-21-04423
T PN: G86C00081410
SPS: M53366-005 0B
FRU: 5W10V25812
WFM: 04CF4B02D433
BDM: 04CF4B02D437
MM: 999M5J
TA: M34062-002

8SSW11A40386
TISS26B22WP
EC: 4372892
Made in China

CRF UK
CE
IC: 1003A-AX211NG
FCC ID: PD3AX211NG

A09-08

Wi-Fi 6E

The image shows an Intel AX211NGW Wi-Fi 6E adapter card on the left. The card's label includes the following information:

- Intel® Model: AX211NGW
- Anatel: 12070-21-04423
- T PN: G86C00081410
- SPS: M53366-005 0B
- FRU: 5W10V25812
- WFM: 04CF4B02D433
- BDM: 04CF4B02D437
- MM: 999M5J
- TA: M34062-002
- 8SSW11A40386
- T1SS26B22WP
- EC: 4372892
- Made in China
- UK CRF, UK CA, CE, and other regulatory logos.
- IC: 1000M-AX211NG
- FCC ID: PD9AX211NG
- Model numbers: A09-08 and E.

On the right, a diagram illustrates the frequency bands and their speeds:

- 2.4GHz**: 574 Mbps
- 5GHz**: 2400 Mbps
- 6GHz**: 2400 Mbps

Bluetooth 5.3

The image shows an Intel AX211NGW Bluetooth 5.3 adapter card on the left. The card's label includes the following information:

- Intel® Model: AX211NGW
- Anatel: 12070-21-04423
- T PN: G86C00081410
- SPS: M53366-005 0B
- FRU: 5W10V25812
- WFM: 04CF4B02D433
- BDM: 04CF4B02D437
- MM: 999M5J
- TA: M34062-002
- 8SSW11A40386
- T1SS26B22WP
- EC: 4372892
- Made in China
- UK CRF, UK CA, CE, and other regulatory logos.
- IC: 1000M-AX211NG
- FCC ID: PD9AX211NG
- Model numbers: A09-08 and E.

On the right, a diagram shows various Bluetooth 5.3 compatible devices:

- Ordinateur Portable (Laptop)
- Bluetooth Écouteurs (Headphones)
- Téléphone Portable (Smartphone)
- Bluetooth Audio (Speaker)
- Tablette (Tablet)
- Bluetooth Manette de jeu (Game Controller)
- Bluetooth Souris (Mouse)
- Bluetooth Imprimante (Printer)
- Bluetooth Clavier (Keyboard)

BT 5.3

Extension du canal Wi-Fi 6E 6Gh



• Step 1

Arrêt de l'ordinateur portable, débrancher l'alimentation, retirer le boîtier arrière de l'ordinateur portable.



• Step 2

Trouvez l'interface correspondant à la carte réseau et retirez l'ancienne carte réseau sans fil.



• Step 3

Insérez la carte réseau dans la fente et accrochez l'antenne, fixez la carte réseau, installez la coque arrière de l'ordinateur portable, démarrez et installez le pilote.



