

MicroBattery 65W Lenovo Power Adapter

20V 3.25A Plug: Square Including Power Cord



Article n °: MBA1091

EAN/UPC: 5711045759826

Réf OEM: 45N0253, 45N0254, 0A36262, 0C19868, 0B47459, FRU45N0254, 4X20E53340, FRU45N0497, 45N0497, 54Y8868, 5A10J75114, 0B47484, 45N0256, 0A36263, 54Y8999, 4X20H15596, FRU45N0495, 0B47455

Liste des modèles compatibles :

- IBM/Lenovo
- IdeaPad S40-70
- IdeaPad S410P
- IdeaPad S510P
- IdeaPad U330 (13.3)
- IdeaPad Yoga 13

- ThinkPad Edge E531
 - Lenovo/IBM
- Essential M5400
- G Series G50-30
- G Series G50-45
- G Series G50-70
- G Series G50-70m
- G Series G50-80
- G Series G70-80
- IdeaPad B50-45
- IdeaPad G400S
- IdeaPad G405S
- IdeaPad G410S
- IdeaPad G500S
- IdeaPad G505S
- IdeaPad S500
- IdeaPad S500 Touch
 - IdeaPad S510P
- IdeaPad Yoga (20C0, 20CD)
 - IdeaPad Yoga 2 Pro
 - IdeaPad Z50-70
 - IdeaPad Z50-75
 - IdeaPad Z710
- ThinkCentre M700 Tiny Form Factor (type 10JQ, 10JR, 10JM, 10JN, 10JS, 10JT)
 - ThinkCentre M710s (Small Form Factor) (type 10M7, 10M8)
 - ThinkPad Edge E431 Non-Touch (6277)
 - ThinkPad Edge E431 Touch (6886)
 - ThinkPad Edge E550
 - ThinkPad Edge E560
 - ThinkPad Edge E565
 - ThinkPad L L440 (20AS, 20AT)

- ThinkPad L L450
- ThinkPad L L460 (20FU, 20FV)
- ThinkPad L L470 (20J4, 20J5)
- ThinkPad L L540 (20AU, 20AV)
- ThinkPad L L560 (20F1, 20F2)
- ThinkPad P P50S
- ThinkPad S S431 (20AX)
- ThinkPad S S440
- ThinkPad S S531 (20B0, 6887)
- ThinkPad S S540 (20B3)
- ThinkPad T T431s
- ThinkPad T T431s (20AA, 20AC)
- ThinkPad T T440
- ThinkPad T T440 (20B6, 20B7)
- ThinkPad T T440p (20AN, 20AW)
- ThinkPad T T440s
- ThinkPad T T440s (20AQ, 20AR)
- ThinkPad T T450 (20BU, 20BV)
- ThinkPad T T450s
- ThinkPad T T450s (20BW, 20BX)
- ThinkPad T T460 (20FM, 20FN)
- ThinkPad T T460s (20F9, 20FA)
- ThinkPad T T470 (20HD, 20HE)
- ThinkPad T T540p
- ThinkPad T T540p (20BE, 20BF)
- ThinkPad T T550 (20CK, 20CJ)
- ThinkPad T T560 (20FH, 20FJ)
- ThinkPad T T570 (20H9, 20JW, 20JX)
- ThinkPad Tablet 11e (1st gen, 20D9, 20DA)
- ThinkPad Tablet 11e (1st gen, 20DB, 20DU) Chromebook
- ThinkPad Tablet 11e (2nd gen, 20E6, 20E8) Intel

- ThinkPad Tablet 11e (2nd gen, 20ED, 20EE) AMD
- ThinkPad Tablet 11e (3rd gen, 20GB, 20G9) Clamshell
- ThinkPad Tablet 11e (3rd gen, 20GD, 20GF) Clamshell Chromebook
 - ThinkPad Tablet Helix
 - ThinkPad W W550s (20E1, 20E2)
 - ThinkPad X X1
 - ThinkPad X X1 (1286)
 - ThinkPad X X1 (1291)
 - ThinkPad X X1 (1292)
 - ThinkPad X X1 (1293)
 - ThinkPad X X1 (1294)
 - ThinkPad X X1 (1295)
 - ThinkPad X X1 (1296)
 - ThinkPad X X1 Carbon (2nd gen., 20A7, 20A8)
 - ThinkPad X X1 Carbon (34xx)
 - ThinkPad X X1 Carbon (3rd gen., 20BS, 20BT)
 - ThinkPad X X1 Carbon (4th gen., 20FB, 20FC)
 - ThinkPad X X1 Hybrid (1286)
 - ThinkPad X X1 Hybrid (1291)
 - ThinkPad X X1 Hybrid (1293)
 - ThinkPad X X1 Hybrid (1294)
 - ThinkPad X X240
 - ThinkPad X X240 (20AL, 20AM)
 - ThinkPad X X240s (20AJ, 20AK)
 - ThinkPad X X250
 - ThinkPad X X250 (20CM, 20CL)
 - ThinkPad X X260 (20F5, 20F6)
 - ThinkPad X X270 (20HM, 20HN)
- Thinkpad Yoga 11e (1st gen, 20D9, 20DA)
- Thinkpad Yoga 11e (1st gen, 20DB, 20DU) Chromebook
 - Thinkpad Yoga 11e (2nd gen, 20E5, 20E7)

- Thinkpad Yoga 11e (3rd gen, 20GA, 20G8)
- Thinkpad Yoga 11e (3rd gen, 20GC, 20GE) Chromebook
 - Thinkpad Yoga 260
 - Thinkpad Yoga 370
- Thinkpad Yoga X1 (Type 20FQ, 20FR)